

USER MENU GUIDE

IMPORTANT: To Unlock the display and access to the menu press the buttons sequence UP – DOWN – UP – DOWN – ENTER.

IMPORTANT: Please note all the default setting are highlighted in a grey color.

Main Menu	Level 1	Level 2	Level 3	Choices / Values
SET UP	DMX Address	→	→	001-512
	Ethernet Interface	Protocol	Disabled	Art-net
			Art-net	
			sACN	
		Custom IP Address	IP address byte 1	000-255
			IP address byte 2	000-255
			IP address byte 3	000-255
			IP address byte 4	000-255
		Custom IP Mask	IP mask byte 1	000-255
			IP mask byte 2	000-255
			IP mask byte 3	000-255
			IP mask byte 4	000-255
		Universe	→	000-255
		Start Channel	→	001-512
		Ethernet to DMX	→	No / Yes
	Wireless Setting	W-DMX On / Off	Off	Off / On
			On	
		Operating Mode	Receive	Receive
			Transmit	
		Transmitting Mode	G3	G3 / G4S
			G4S	
		Link	Link	
			Unlink	
		Receive Reset	No	
			Yes	
		Wireless to DMX	No	Yes / No

Main Menu	Level 1	Level 2	Level 3	Choices / Values
OPTION	Lamp DMX	→	→	On / Off
	Safety Black Out	→	→	On / Off
	Pan / Tilt	Invert Pan	→	On / Off
		Invert Tilt	→	On / Off
		Swap Pan-Tilt	→	On / Off
		Encoder Pan-Tilt	→	On / Off
		P/T Homing mode	→	Standard
				Sequenced
		Pan Home Def Pos	→	0 degree
				90 degrees
				180 degrees
				270 degrees
		Tilt Home Def Pos	→	0 %
				12.5 %
				25 %
				50 %
				75 %
				87.5 %
				100 %
		Pan / Tilt Speed	→	Standard
				Fast
	Shutter	Shutter On Error	→	On / Off
	Reflection	→	→	On / Off
	Display	→	→	On / Off
	Setting	Default Preset	Reset To Default Go Back	Are you sure ? Yes / No
		User Preset 1	Load preset 1 Save to preset 1	Are you sure ? Yes / No
		User Preset 2	Load preset 2 Save to preset 2	Are you sure ? Yes / No
		User Preset 3	Load preset 3 Save to preset 3	Are you sure ? Yes / No

Main Menu	Level 1	Level 2	Level 3	Choices / Values
INFORMATION	System Errors	→	→	
	Fixture Hours	Total Hours	→	Read
		Partial Hours	→	Read / Reset
	Lamp Hours	Total Hours	→	Read
		Partial Hours	→	Read / Reset
	Lamp Strike	Total Hours	→	Read
		Partial Hours	→	Read / Reset
	System Version	Disp	→	Fw.rev.
		Net	→	Fw.rev.
		Ctr1 - XY	→	Fw.rev.
		Ctr2 - Motor	→	Fw.rev.
		Ctr3 - Motor	→	Fw.rev.
		Ctr4 - Motor	→	Fw.rev.
		Ctr5 - Motor	→	Fw.rev.
	DMX Monitor	Channels	→	Bit
	Network parameters	→	→	IP Address
				IP Mask
				MAC Address
	UID	→	→	UID: xxxxxxxxx
	Temperature	→	Head Temperature Base temperature	xx° C xx° C
MANUAL CONTROL	Lamp	→	→	On / Off
	Reset	→	→	Yes / No
	Channel	→	→	Bit Value
TEST	→	→	→	Pan / Tilt
	→	→	→	Colour
	→	→	→	Beam
	→	→	→	Gobo
	→	→	→	All
ADVANCED	Access Code <u>1234</u>	Upload Firmware	Transfer	Are you sure ? Yes / No
		Calibration	Channels	000 - 255
		Menu Locking	→	Unlock Code <u>1234</u>
		Recover	→	Countdown 60s Are you sure ? Yes / No

SETUP MENU

Setup - DMX ADDRESS

PLEASE NOTE: Without the DMX input signal, the displayed show No Signal on it.
DMX address between 001 and 512 can be selected.

Setup - ETHERNET INTERFACE

Protocol

Allow to define protocol

Custom IP Address

Allow to define "IP Address"

Custom IP Mask

Allow to define "IP Mask",

Universe

Allow to define "DMX Universe" between 000 and 255.

Start Channel

Allow you to define the protocol start channel from 001 and 512.

Ethernet to Dmx

Enable/Disable the transmission of the Ethernet protocol by DMX signal

- NO: DMX transmission disabled. / YES: DMX transmission enabled.

Setup – WIRELESS SETTING

W DMX On/Off

Enable/Disable the W-DMX

Operating mode

Allow you to set the operating mode:

Transmit: allow to create connection with another transmitter

Receiver allow to create connection with another receiver

Transmitting mode

Allow to set the wireless transmitting mode:

- G3
- G4S

Link

Allows you to link/unlink receivers

If the fixture is set as "Transmit mode", allow to create the connection with another receiver device.

Receive Reset

Allow you to reset the receive configurations

If the unit is set in "Receive mode", before to create the connection with another transmitter unit, it should set "Yes" to disconnect (reset) with previous connection.

W DMX to Dmx

Enable/Disable the transmission of the Wireless protocol by DMX signal

- NO: DMX transmission disabled.
- YES: DMX transmission enabled.

OPTION MENU

Option – LAMP DMX

Lamp DMX

Allows you to switch ON or OFF the lamp from remote control channel

Option – SAFETY BLACK OUT

Safety Black Out

This allows the Dimmer's automatic lock option to be activated (ON) after 3 seconds with no incoming DMX signal. Select OFF to turn off or disable this option.

Option - PAN / TILT

Invert Pan

It lets you enable (ON) Pan reverse movement. Select OFF to turn off or disable this option.

Invert Tilt

It lets you enable (ON) Tilt reverse movement. Select OFF to turn off or disable this option.

Swap Pan-Tilt

It lets you enable (ON) Pan and Tilt channel inversion (and simultaneously Pan fine and Tilt fine). Select OFF to turn off or disable this option.

Encoder Pan-Tilt

It lets you enable (ON) or disable (OFF) Pan and Tilt Encoder operations.

P/T Homing Mode

It lets you set the initial Pan and Tilt Reset mode.

- **Standard:** Pan & Tilt are simultaneously reset.
- **Sequenced:** Tilt is reset first followed by Pan.

Pan Home Def Pos

It lets you assign the Pan channel "home" position at the end of Reset (without a DMX input signal), selecting one from the 4 available positions:

- **0 degree**
- **90 degrees**
- **180 degrees**
- **270 degrees**

Tilt Home Def Pos

It lets you assign the Tilt channel "home" position at the end of Reset (without a DMX input signal), selecting one from the 7 available positions:

- **0%**
- **12.5%**
- **25%**
- **50%**
- **75%**
- **87.5%**
- **100%**
-

P/T Speed

It lets you select the Pan & Tilt speed.

- **Standard**
- **Fast**

OPTION MENU

Option – SHUTTER ON ERROR

Allows you to activate (ON) automatic "Stopper/Strobe" closing in the event of Pan/Tilt positioning error. Select OFF to turn off or disable this option.

Option – REFLECTION

Allows you to activate (ON) the option that "hides" a projection reflection of the fixed Gobi wheel in some particular conditions of use.

Option – DISPLAY

Allows you to activate (ON) display brightness reduction after about 30 seconds in idle status. Select OFF to turn off or disable this option.

Option – SETTING

Used to save 3 different settings of the items in the option menu and relevant submenus.

- Default preset (*)
- User preset 1
- User preset 2
- User Preset 3
 - **Load preset 'X'** is used to recall a previously stored configuration.
 - **Save to preset 'X'** is used to save the current configuration.

(*) DEFAULT PRESET

It lets you restore default values on all option menu items and relevant submenus.

INFORMATION MENU

Information – SYSTEM ERRORS

It displays a list of errors that occurred when the fixture was turned on.

To reset the SYSTEM ERRORS list, press OK. A confirmation message appears (Are you sure you want to clear error list?). Select YES to confirm reset.

Information – FIXTURE HOURS

It lets you view fixture working hours (total and partial).

Total counter

It counts the number of fixtures working life hours (from construction to date).

Partial counter

It counts the number of fixture partial working life hours from the last reset to date.

Press OK to reset the partial counter. A confirmation message appears on the display (Are you sure ?)
Select YES to confirm reset.

Information – LAMP HOURS

It lets you view lamp working hours (total and partial).

Total counter

It counts the fixture working hours with the lamp on (from construction to date).

Partial counter

It counts the lamp partial working hours from the last reset to date.

Press OK to reset the partial counter. A confirmation message appears on the display (Are you sure ?)
Select YES to confirm reset.

Information – LAMP STRIKES

Allows you to view how many times the lamp was turned on (total and partial).

Total counter

It counts how long the lamp has been on (from construction to date).

Partial counter

It counts the number of times the lamp was turned on from the last reset to date.

Press OK to reset the partial counter. A confirmation message appears on the display (Are you sure?)
Select YES to confirm reset.

INFORMATION MENU

Information – SYSTEM VERSION

It lets you view the hardware and software versions for each electronic board in the projector.

- Disp
- Net
- Ctr1-XY
- Ctr2-Motor
- Ctr3-Motor
- Ctr4-Motor
- Ctr4-Motor

Information – DMX MONITOR

It lets you view the level of projector DMX channels in bit.

Information – NETWORK PARAMETES

Let you view the projector "Network" parameters meaning:

IP address:

Internet Protocol address (two projectors must not have the same IP address)

IP mask:

255.0.0.0

Mac address:

Media Access Control; the projector's Ethernet Address

Information – UID

Shows the exclusive address of the fixture to use communicate via RDM.

Information – TEMPERATURE

Let you view the temperature inside the Head and the Base of the fixture.

MANUAL CONTROL

Manual Control - LAMP

Allows you to turn the lamp on (ON) or off (OFF) from the projector control panel.

Manual Control - RESET

Allows you to reset the fixture from the projector control panel.

Manual Control - CHANNEL

Allows you to set the channel DMX levels from the projector control panel (value between 0 and 255 bit).

TEST MENU

It lets you test the correct operations of effects using pre-saved Tests:

- Pan/Tilt
- Colour
- Beam
- Gobo
- All

ADVANCED MENU

To log into the “Advanced Menu”, enter the code (1234)

Advanced - UP LOAD FIRMWARE

It lets you transfer the firmware from one fixture to all the other connected to the same DMX line. A confirmation message will appear on the display “Are you sure?” Select YES to confirm or NO to abort the operation.

IMPORTANT: We recommend uploading the firmware to a maximum 5/6 units per time.

Advanced - CALIBRATION

It lets you make small mechanical adjustments on some effects to perfectly align projectors from the control panel.

Advanced – MENU LOCKING

It allows you to assign a password to lock the access to the user menu, so that only users know the password can change settings. The password is 4-digit number. Default Unlock Code is :1234.

Advanced – RECOVER

The recover function allows to restore the functionality of the electronic boards following a failure during the firmware update process of the fixtures. Please refer to the “Recover function” tech document for the detail of the procedure.